



Model: 15034P

Les Attaches de Remorque SRG, inc.

Date: 02/21/2003

Installation guide

1. there are 2 shapes molded into the trunk floor (on either side of the light molding)
2. insert the angled plated into these shapes and drill the holes through the trunk floor
3. fasten the trailer hitch to these plates
4. fasten the angle bracket to the rear trailer hitch hole
5. drill the angle bracket holes through the trunk floor
6. fasten the angle bracket by using the supplied square plates inside the trunk

Supplied hardware

6 --- 10 mm flat washers	4 --- 10 mm lock washers	2 --- 12 mm flat washers
6 --- 10 mm nuts	1 --- 12 mm lock washer	1 --- square plates
2 --- 10 x 30 bolts	1 --- 12 mm nut	2 --- angle plates
4 --- 10 x 40 bolts	1 --- 12 x 40 bolt	

Guide d'installation

1. Il y a deux formes, encavées dans le fond de la valise (de chaque côté près de la paroi des lumières)
2. Placez les plaques avec angles dans les formes encavées et percez les trous dans le fond de la valise
3. Reliez l'attache de remorque à ces plaques
4. Fixez la plaque pliée au trou arrière l'attache de remorque
5. Perforez les trous de la plaque pliée dans le fond de la valise.
6. Fixez la plaque pliée en insérant les plaques carrées à l'intérieur de la valise

Quincaillerie fournie

6 --- rondelles plates 10 mm	4 --- rondelles freins 10 mm	2 --- rondelles plates 12 mm
6 --- écrous 10 mm	1 --- rondelle frein 12 mm	2 --- plaques carrées
2 --- boulons 10 x 30	1 --- écrou 12 mm	
4 --- boulons 10 x 40	1 --- boulon 12 x 40	